



HQ Scales, Inc
measurement in motion

(815) 249-9840

hqcales.com

1741 Industrial Drive
Unit 6
Sterling, IL 61081 USA

sales@hqcales.com




WiFi INTEGRATOR

SCALE WEBPAGE

The HQ Integrator comes equipped with a WiFi webpage. Simply use your smart phone's web browser to see real time data. Alternatively, connect to a local area network and view on your PC. No subscription necessary.

- Rate & Speed
- Daily Report & Scale Totals
- Scale Sensor Readings
- Download +/- 30 Days of Production Info to .CSV file
- View Calibration Info
- Perform Zero Calibration
- View Production Info



CUSTOMIZE

Define Scale Name, Material, and Job




WiFi RANGE

+/- 50ft with line of sight or connect the scale to your local network



REPORTING

Monitor the scale via the webpage send PDF's or .CSV files via text or email



EASE OF USE

Simple User Interface

INTEGRATOR SPECS



Simple Configuration and Calibration

Easy To Use Interface for Daily Operation

Compatible with Most Other Conveyor Belt Scale Brands

- Rugged Outdoor Steel Enclosure
- NEMA 4X
- 12-24VDC or 110-220 VAC
- 4 Load Cell Inputs
- 1 Speed Sensor Input
- 1 Angle Sensor Input
- Ethernet Port
- Built In WiFi Webpage
- Modbus TCP
- RS485
- Accessory Power Ports
- Scoreboard Compatible
- Optional IO Board
 - 2 Digital Outputs
 - 2 Analog 4-20mA Outputs

NETWORK SETUP

Customers can easily customize the network settings to fit their own requirements.

- WiFi SSID is the Integrator Serial Number
- Modify the Network settings when connecting to Wireless or Hardwired Networks



EXTEND WIFI RANGE

Add a wireless repeater to extend the wifi range up to 500ft.

